


1 System Configuration

1.1 System Basic Configuration Drawing



(Note 1) Control unit is mounted on the back side of the display unit.

(Note 2) Operation panel I/O unit is mounted on the back side of the keyboard unit.